

<b>USB Port Printer List</b>		
<b>Brand</b>	<b>Type</b>	<b>Model</b>
<b>HP</b>	Deskjet	640C, 656C, 845C, 920C, 948C, 960C, 990CXI, 995C, 125C, 1180C, 3420, 3425, 3535, 3745, 3845, 5600, 5625, 6100, 940C
	Inkjet	DJ 5150, DeskJet5610, DeskJet5650, DeskJet5850, DJ 710C, DJ990 CSE, CP1700, OJ 7110
	Laserjet	5, 5MP, 6MP, 1012, 1200, 1320, 2200, 2300, 2200D, 1500(USB 2.0)
<b>LexMark</b>		Z13, Z43, Z53, Z25, Z45, Z810, Z818, 4039 10R, 5700, Optra Color 45, Optra C710, Optra E, E+, E310, E230, Optra K1220, Optra M410, M412, Optra N, Optra R+, Optra S1250, Optra S1855, Optra SC-1275, Optra SE-3455, OptraT614, Optra W810
<b>Canon</b>		S100SP, S200, S200SP, I250, I320, S300, S330, MP360, S400SP, S520, S600, S6300, S750, S450, S4500, S9000, PIXUS 850i, BJC55, BJC85, I850, IP3000, IP4000
<b>EPSON</b>	Stylus	C41UX, C405, C60, C61, C80, C42UX, RX510, C43, C45
	Photo	R310, 720, 810, 820, 825, 830, 830U, 890, 900, 1280, 1290, PM860PT, CC550L, CC570L, CL750, CL760, MC-2000, PM680C, PM-720C, PM-730C, PM-740C, PM740DU, PM-D750, PM-780CS, PM-790PT, PM-800C, PM-800DC, PM-820C, PM-820DC, PM-830C, PM-840C, PM-850PT, PM-860PT, PM-870C, PM-890C, PM-G900, PM-920C, PM-930C, PM-940C, PM-950C, PM-970C, PM-980C, PM-D1000, PM-2200C, PM-3300C, PM-3500C, PM-3700C, PM-4000PX, PM-A850, PM-D750, PM-G700, PM-G800, E-100
	Laser	PX-V500, PX-V600, PX-V700, PX-G900, 900, 1160, 2200, LP-1200, LP-1300, LP-1400, LP1500C, LP-2000C, LP-2400, LP-2500, LP-6100, PX-6400, LP-7000C, LP-7500, LP-7700, LP-7800, LP-7900, LP-8900, LP-9000B, LP-9000C, LP-9100, LP-9400, LP-9500C, LP-9800C
	All in One Officejet	PM-A850, CC-600PX

\*The above printers have been tested, but under different environments results may be different. If your printer is not on the list, it still may work.

<b>Unsupported printer</b>		
HP		Laser Jet 1000 serial (DGI printer), Office Jet serial (multi-function machine), 2500C, 2410Xi, 5000, 6210, OJ6110, OJ G55, DJ882C, DJ3320, DJ2200, LJ3100, LJ200
Canon		CAPT printer, I80, I860, I455, I450, IP2000, IP5000, MP390, MP730, MP750
Lexmark		Z23, Z54, Z515, Z605, Z615, Z700 E210, E232, x6170, x7170

\*The above printers were reported not working, but under different environments results may be different